


CDOT Traffic ITS Striping Menu



This document guides you through the functionality of the CDOT Traffic ITS > Striping Menu. The CDOT Menu is designed so that the user can effortlessly maintain the Department's drafting standards. Each command selected from menu will automatically set the correct level and symbology for the element to be placed. It also launches the MicroStation command needed to place the element. The menu should also be used to set symbology even when a different command will be used to place an element.


The CDOT Menu Explorer (left pane of the dialog box) separates the menu options based on specialty groups. The Drafting option will be used by all groups. Some menu options assigned to a specialty group may also be required by another, so be sure to check the other specialty groups' menu options if a command or symbology is not found within your group.

1. The **Material** pull down menu located directly above the Selection List determines what Category options are available.




CDOT Traffic ITS Striping Menu.pdf

2. Select one of the Category buttons on the left side of the **Striping** area to begin defining the element to be placed. The choices of buttons will change based on the Status selected. The Category buttons for Preformed Plastic and Thermo are shown on the menu. The Category buttons for Epoxy are shown in the inset.




Note: The Traffic ITS Striping menu only contains proposed elements so the Status window will not be used

3. If desired, select one of the Filter buttons above the selection list. These are used to limit the selection list to a specific type of element. The illustration below identifies the element types displayed by each Filter button.



CDOT Traffic ITS Striping Menu.pdf


4. Select the desired Item from the Selection list and place the element.



Settings Options

The Settings options are used to change the scale and angle at which elements are placed


5. The **Active Scale** and **Active Angle** settings are accessed from the **Settings** button on the CDOT Menu.
6. To change the **Active Scale** or **Active Angle**, key-in the desired value in the appropriate field. **Note:** the Active Angle is view independent and not associated with view rotation. Therefore, the x-axis is always horizontal regardless of the view rotation.




CDOT Traffic ITS Striping Menu.pdf

The Cell Preview Window

7. To see a preview of a cell, <D> on the cell name in the list. The cell is then displayed in the preview window.



8. The **Cell Preview Window** can be relocated within the CDOT Menu. It may reside under the **Menu Explorer** (left) or under the **Category icons** (right).



To move the **Cell Preview Window**, <D> and hold on the window, drag it to the new location, and release the mouse button.