

InRoads

Points to End of Feature

Did you know to add points to the end of a feature, use the Surface > Design Surface > Place Feature command with the *Append* option turned on. If you want to add points to the start of the feature: first use the Surface > Edit Surface > Reverse Feature Direction command to reverse the order of the points.