

Work flow for establishing a CDOT code library for the Data Collector and TGO

- Load the *.ddf file from the CDOT website into the data collectors. (note: To my knowledge the *.ddf file can only be used in the Trimble data collectors, we have a SDR library, attributes only available at the same location.)
- When you create your daily file in the field you must select the library you have uploaded into the data collector. The data collector should then prompt you for the information needed to be associated with any single shot.
- Download the *.fcl file from the CDOT website(not currently available on the website).
- Open a new project in TGO and go into the project properties and then select the features tab. Then check the boxes for the feature code on import and use attributes and browse to the appropriate folders where the *.fcl resides.