

CDOT Parcel Type Prefixes for Right of Way Plans

Letter - Meaning

AC - Access

AP - Advance of Plans

EA - Early Acquisition

EX - Excess parcel

HS - Hardship parcel

ME - Mineral Estate

MS - Maintenance Site

PB - Protective Buy

PE - Permanent Easement

RE - Railroad Easement

RM - Remainder or Remnant Parcel

RW - Right of Way

SE - Slope Easement

SN - Signs

SV - Scenic Vista

TE - Temporary Easement

UE - Utility Easement

UN - Unknown

WH - Wildlife Habitat

WL - Wetland

XX - Only For Conversion Purposes