## See Chapter 2 of the Right of Way Manual Section 2.6.5 - Parcel Designations

## CDOT Parcel Type Prefixes for Right of Way Plans

## Letter - Meaning

- AC Access
- AP Advance of Plans
- EA Early Acquisition
- EX Excess parcel
- HS Hardship parcel
- ME Mineral Estate
- MS Maintenance Site
- PB Protective Buy
- PE Permanent Easement
- RE Railroad Easement
- RM Remainder or Remnant Parcel
- RW Right of Way
- SE Slope Easement
- SN Signs
- SV Scenic Vista
- TE Temporary Easement
- UE Utility Easement
- UN Unknown
- WH Wildlife Habitat
- WL Wetland
- XX Only For Conversion Purposes