

November 30, 2006

REVISION OF SECTION 101
FALSEWORK, FORMWORK AND SHORING

Section 101 of the Standard Specifications is hereby revised for this project as follows:

Add subsection 101.89 as follows:

101.89 Falsework. Falsework is temporary construction used to support structural elements of concrete, steel, masonry or other materials during their construction or erection until they become self-supporting. Falsework may also be used to provide temporary support to elements of a structure during demolition or reconstruction.

Add subsection 101.90 as follows:

101.90 Formwork. Formwork is the temporary structure or mold used to retain plastic or fluid concrete in its designated shape until it hardens.

Add subsection 101.91 as follows:

101.91 Shoring. Shoring is temporary construction that is used to support the earth adjacent to excavation or embankment.