InRoads

Point Snap

Did you know that when selecting a station for a range with Point Snap on, you can select only cardinal points along as alignment? With Point Snap off, you can select intermediate stations along an alignment.