

InRoads

Setting Alignment Points based on other Alignments

Did you know that you can set an alignment point based on an existing alignment that is loaded in memory by using Station and Offset? When in Place or Move PI, type in “so=station, offset, {elevation, existing alignment name, geometry project name}”.