

InRoads

Adding and Subtracting an Angle in InRoads

Did you know that you can add or subtract from an angle value while keying it in by adding a + or - and the amount to be added or subtracted? The software will automatically do the math before sending the value to the command.