

## InRoads

### *Feature and Graphic Lock Toggle*

**Did you know** that you can toggle the Locate lock between Locate Features and Locate Graphics while selecting elements during the Surface > Design Surface > Transverse Feature, Longitudinal Feature, and Sloped Surface commands without exiting the commands.