

InRoads

P & P Generator Tip

Did you know that when running the Evaluation > Plan and Profile Generator command, turn Generate Sheets off and run Plan Only method until you have all the plan views at the desired locations. Then use the Plan and Profile method in the Use Plan Views mode to create the associated Profile views.