

InRoads

Profile Shift in P&P Generator

Did you know that only the highlighted surfaces on the Profile Controls tab will be used to determine if the profile needs to shift when running the Evaluation > Plan and Profile Generator command.