

InRoads

What size pipe am I?

Did you know that if you are trying to determine what size a pipe is in an existing survey, that you can open up the existing dtm surface, use the Surface pulldown in InRoads and View Surface feature and select the pipe in question with the target button and then annotate the feature. Each pipe contains the feature style name that matches the type of pipe and the size of pipe that has been located in the field. It will also display the slope when annotating.

Submitted by Corey Guerrero