

# MicroStation

## ***Boresite Lock***

**Did you know that** if you are having difficulty selecting graphics within your DGN file, then it may be relative to your Boresite Lock being turned off. Boresite Lock makes it easier when using data points (alone) to identify elements. With Boresite Lock on, data points will find elements at all depths of a view. When Boresite Lock is off, data points (alone) will identify only those elements that are lying on or near the active depth for the view. Whether Boresite Lock is on or off, still you can snap to elements at any depth in a view. The lock should be turned on by default in the CDOT workspace. See Settings > Locks > Boresite on the MicroStation Pulldowns.