

# MicroStation

## Modifying Auto-Dimensioning

**Did you know** that after placing Linear Dimensioning you can use several of the Modify Element commands on the dimension. The Modify Element command allows you to modify the extension line and re-associate it's start or stop position. It also allows you to reposition the text that has been placed with the Dimension string. The Insert Vertex allows you to insert additional dimension breaks along a previously placed dimension string, while the Delete Vertex allows you to delete dimension breaks.

Sometimes it is easier to simply redraw the dimension all together, other times it may be better to modify it. Try it, you may like it.