

# MicroStation

## *PDF Printing*

**Did you know** when printing a PDF file you may need to turn off the Page Scaling on the print dialog box. Under the Page Handling area, notice the Page Scaling:, Select the pull-down and choose None. This will allow the saved PDF files to be "to scale" when measured with an Engineering scale, similar to a regular print from MicroStation. [Click Here](#) to view the affected dialog box.

# Print



## Printer

Name: \\print\PDEV01L

Properties

Status: Ready

Comments and Forms:

Type: HP LaserJet 9000 PS

Document

## Print Range

All

Current view

Current page

Pages from: 1 to 1

Subset: All pages in range  Reverse pages

## Page Handling


Copies: 1  Collate

Page Scaling: None

- Auto-Rotate
- Choose Paper

## Preview

8.5



11

Document: 8.5 x 11.0 in

Paper: 8.5 x 11.0 in

1/1 (1)

Printing Tips

Advanced

OK

Cancel